
# MD22xx barcode scanner quick guide

- A standard packing includes a scanner, a PS2 cable and a CD (or a user manual).
- Accessories include a stand, a RS232 cable, a 5V adaptor and a USB cable.
- Use a piece of dry and soft cloth when cleaning the scanner.

#### Parts of the scanner



- ① LED
- ② Exit window
- 3 Trigger
- 4 Cable interface port
- (5) Release-hole of the cable
- 6 Beeper

#### Installing the cable

- 1. Switch off the host;
- 2. Refer to the below pictures, connect the host with the scanner based on different cables;
- 3. Ensure that all connections are secure.
- 4. Switch on the host system. If installation is successful, the beeper will beep and LED will light.



# Removing the cable

- 1. Find the release-hole.
- 2. Insert a thin wire into the hole and pull out the cable gently.

#### Special setting







Default value initialization




Firmware version list

# Programming instruction and example





# Assembling the stand (accessory)



- 1. See the figure above, tighten the screws.
- 2. Bend the neck to the desired position for scanning.
- 3. Screw mounting: Screw one #10 wood screw into each screw-mount-hole until the base of the stand is secured.
- 4. Tape mounting: ①Peel the paper liner off one side of each piece of tape and place the sticky surface over each of the three rectangular tape holders. ②Peel the paper liner off the exposed sides of each piece of tape and press the stand on a flat surface until it is secure.

Note: 1. More details refer to User Manual; 2. For better readability, please print this document with laser printer. 3. Version: MD22xx QG EN V1.2.3.